

MIXING POROTHERM MORTAR



You will need:

- Safety gear: Glass, dust mask, gloves
- Mortar
- Mixing tub or bucket
- 10L Water/bag of mortar (be exact to get the creamy result)
- Paddle mixer
- Power

If this is your first mix and you don't have any experience, please mix only the half of the bag first.

Instruction for half bag of mortar:

- 1./ Pour 5L water into the bucket.
- 2./ Pour the half bag of mortar into the bucket/tub.
- 3./ Start mix slowly
- 4./ Mix all together for 5 minutes. Please ensure that you scrape any unmixed mortar from the inside surface of the tub.
- 5./ Leave for stand for circa 3-5 minutes.
- 6./ Remix again for 3-5 minutes.
- 7./ The result should be creamy mortar. Before you pour into the Roller, please make sure the roller is clean and oiled.

The best of luck with your build

Clayblock Ireland